

MA 1140/MA 1250

Manual fusing press with support table.

Suitable for fusing work on jackets parts such as sides, lapels, and trouser waist band area. Manual top plate by a lever.

There is a 0-220°C electronic thermostat and beeping warning for the end of working time.

Extra accessories: base of supporting the press

Working Surface:.....110 x 40cm (MA 1140)/ 120 x 50cm (MA1250)

Heating Power:.....3kW (MA 1140) / 3.6kW(MA 1250)

Temperature:.....0-220°C

Power Supply:.....230V-1ph-50Hz



Model	Code	Features	Volt	Heating	Working Surface cm
MA 1140	105-01-000	Manual fusing press	230	3	110 x 40
MA 1250	105-14-001	Manual fusing press	230	3.6	120 x 50

Accessories:

Model	Code	Description
BASE FOR MA1140	105-01-002	Base for supporting the press MA1140
BASE FOR MA1250	105-14-003	Base for supporting the press MA1250

AU 1140/AU 1250

Automatic fusing press with support table.

Suitable for fusing jackets parts such as sides, lapels, and trouser waist band area. Automatic top plate by two buttons.

There is 0-220°C electronic thermostat and beeping warning for the end of working time..

Extra accessories: base of supporting the press

Working Surface:.....110 x 40cm (AU 1140) / 120 x 50cm (AU1250)

Heating Power:.....3kW (AU 1140) / 3.6kW(AU1250)

Temperature:.....0-220°C

Working Pressure:.....6bar

Air consumption:.....50L/min

Power Supply:.....230V-1ph-50Hz



Model	Code	Features	Volt	Heating kW	Working Surface cm
AU 1140	105-01-001	Pneumatic fusing press	230	3	110 x 40
AU 1250	105-14-002	Pneumatic fusing press	230	3.6	120 x 50

Accessories:

Model	Code	Description
BASE FOR AU1140	105-01-002	Base for supporting the press AU1140
BASE FOR AU1250	105-14-003	Base for supporting the press AU1240